FABRIC & CARE CARD

Anchor, Antler, Barn, Bittersweet, Calypso, Copper, Elk, Hazelnut, Lakefront, Oxford, Port, Sandstorm, Shiraz & Sterling

Fiber Content Face & Back: 100% Polyester

Cleaning Code: W



with STAIN DEFENSE



GENERAL CARE HINTS:

- 1. Spot clean only with water based shampoo or foam upholstery cleaner (it is recommended to pretest small area prior to proceeding).
- 2. Pile fabric can be brushed with a non-metallic, stiff brush to restore appearance.
- 3. Frequent vacuuming or light brushing will help to remove dust & grime.
- 4. Blot spills immediately.
- 5. Clean spots or stains from the outside to the middle of the affected area to prevent circling.
- 6. Use a professional cleaning service when an overall soiled condition has been reached.

NOT RECOMMENDED:

- Solvents
- Over-wetting
- Water extraction or steam cleaning methods

BRISA[®] | ORIGINAL & DISTRESSED FABRIC & CARE CARD

Brisa | Original: Beet Root, Black Onyx, Coffee Bean, Cream, Iron, Shiitake & Night Navy

Brisa | Distressed: Bridle, Buckskin & Saddle

Fiber Content:

Face: 100% Polycarbonate Polyurethane Back: 65% Polyester, 35% Rayon

Cleaning Code: S

In a category of its own, Brisa is designed, engineered and handcrafted with softness, beauty, and durability in mind.

Original has a subtle grain that simulates a genuine leather but with a supple feel. Distressed has a classic, relaxed grain with natural-inspired colorations.







Brisa

CARE HINTS BENEFITS:

- Stain and blemish-resistant
- Resists stiffening and cracking
- Luxuriously soft and comfortable
- Stays cooler than leather in warm weather conditions and warmer in cold weather conditions.
- Effortless cleaning!

CARE HINTS:

- Cleans effortlessly with soap and water
- Lifts most stains with alcohol-based solutions like Fantastik® and 409®
- Disinfects with 5:1 bleach/water solution

MICROSUEDE FABRIC & CARE CARD

Fabric:

Bourbon & Smoke

Fiber Content:

Face: 95% Polyester, 5% Polyurethane Back: 95% Polyester, 5% Polyurethane

Cleaning Code: W

Microsuede fabric is a stylish alternative to suede with wonderful advantages. Made of 95% polyester and 5% polyurethane, this microsuede fabric is soft to the touch and easy to care for. Composed of millions of microfibers, it has the soft hand of natural suede leather but none of its drawbacks. The napped surface feels like genuine suede. Long-lasting and stain-resistant, this vegan faux suede fabric is perfect for furniture that will see a high volume of use or spills and comes in a variety of colors to match any home décor. 100% Vegan but looks and feels like the real thing.



GENERAL CARE HINTS

- Spot clean only with water based shampoo or foam upholstery cleaner (it is recommended to pretest a small area prior to proceeding).
- 2. Do not overwet. Do not use solvents to spot clean.
- 3. Hot water extraction or steam cleaning is not a recommended cleaning method.
- 4. To prevent overall soiling, frequent vacuuming or light brushing with a non metallic, stiff bristle brush is recommended.
- 5. When cleaning a spill, blot immediately to remove spilled material.
- 6. Clean spots or stains from the outside to the middle of the affected area to prevent circling.
- 7. Use a professional cleaning service when an overall soiled condition has been reached.

NOT RECOMMENDED:

- Solvents
- Over-wetting
- Water extraction or steam cleaning methods

FAUX LEATHER FABRIC & CARE CARD

Fabric:

Graphite & Maple

Fiber Content:

Face: 100% Polyester Back: 100% Polyester

Cleaning Code: W

Sutton faux leather is a rich and modern alternative to natural leather that is extremely comfortable while offering the rugged durability of leather. Made from 100% polyester, the fabric is easy to care for ensuring functionality as well as elegance. This long-lasting fabric will complement a variety of decors while standing the test of time under heavy use.



GENERAL CARE HINTS

- Spot clean only with water based shampoo or foam upholstery cleaner (it is recommended to pretest a small area prior to proceeding).
- 2. Do not overwet. Do not use solvents to spot clean.
- 3. Hot water extraction or steam cleaning is not a recommended cleaning method.
- 4. To prevent overall soiling, frequent vacuuming or light brushing with a non metallic, stiff bristle brush is recommended.
- 5. When cleaning a spill, blot immediately to remove spilled material.
- 6. Clean spots or stains from the outside to the middle of the affected area to prevent circling.
- 7. Use a professional cleaning service when an overall soiled condition has been reached.

NOT RECOMMENDED:

- Solvents
- Over-wetting
- Water extraction or steam cleaning methods

HIGH-PERFORMANCE FABRIC & CARE CARD

Fabric: Carbon, Limestone & Shale

Fiber Content:

Face: 100% Polyester Back: 100% Polyester

Cleaning Code: W



Alta[™] delivers the highest repellency, cleanability and a complete liquid barrier for upholstery fabrics in highperformance environments. High repellency to stains and spills, including complex oil-based stains. Exceptional cleanability, reduces the need for harsh cleaning agents. Durablock[™] liquid barrier provides breathable protection. Antimicrobial protection controls odors, stains, mold, and mildew.



CLEANING INSTRUCTIONS GENERAL CARE:

This high performance technology minimizes staining, building a permanent spill resistance into the fiber structure of the fabric. However, cleaning may still be necessary to maintain the original look of the fabric.

STAIN REMOVAL: W-

1. Liquid spills: Don't wait! Blot liquid quickly and gently with a clean, dry, absorbent cloth. If liquid remains, continue with gentle blotting. Gently remove any soil or debris from the surface. No rinsing needed.

2. If any residual spot remains: Flush liberally with warm water and blot with a clean, dry, absorbent cloth. Change blotting cloth surface frequently, until spot is gone. (Avoid brushing which can spread the stain!) Repeat process until spot has been removed. Finish with final warm water rinse and blot.

3. For difficult or stubborn stains: Mix 2-3 drops of any mild laundry detergent with 1 cup of water and apply to soiled area. Gently work solution into the area, wait several seconds and blot the spot with a clean, dry, absorbent cloth. Repeat until spot has been completely removed. Rinse thoroughly with warm water and blot to remove any soap residue.

FABRIC & CARE CARD

Fabric: Chestnut, Cobalt, Eclipse, Geranium Fiber Content: 65% Resin, 35% Woven Backing Cleaning Code: S

URETHANE



CLEANING INSTRUCTIONS

GENERAL CARE:

While this material is inherently stain resistant, it is important to keep it clean at all times to maintain the original look and the rich feel.

STAIN REMOVAL:

 S - To prevent overall soil, frequent vacuuming or light brushing to remove dust and grime is recommended. Spot clean using a mild water-free solvent or dry cleaning product. Clean only in a well ventilated room and avoid any product containing carbon tetrachloride which is highly toxic. Pretest small area before proceeding. Cleaning by a professional furniture cleaning service only is recommended.



What is SmartTek[®] ?

SmartTek is a patented self-diagnostic technology standard on all Golden lift chairs.

What does it do?

SmartTek notifies you if there is a malfunction in the chair.

How does this benefit me?

Most malfunctions can be diagnosed and solved over the phone saving you time and inconvenience. When a malfunction does require a service call, using the SmartTek technology, the technicians will have a better understanding of what parts they will need to repair the malfunction before they leave the office.



HOW IT WORKS

There is a green LED light display on the hand control, a second on the wire that plugs into the transformer, and a third on the transformer. If one or all of these lights are off, the user will know there is a malfunction with the chair.

If all LED lights are off, first check that chair is plugged in, that the fuse or breaker is working, and all other connections are functioning properly. Check these first.

When the green LED on the transformer is not lit, —possible transformer malfunction.

When the green LED on the hand control is not lit and the chair is not working —possible defective hand control or extension wire.

When the green LED on the motor wire is not lit, —possible motor malfunction.

If all LED lights are on, and the chair runs only in one direction —possible hand control is defective.

If all LED lights are on, but the chair does not work —possible defective motor or hand control.